UPDATED ONLINE USER GUIDE

The WorldNav GPS software has been upgraded to a newer version than what is shown in the enclosed user guide. View the updated online user guide at:

http://www.teletype.com/pages/support/Documentation/WorldNav3100Manual.pdf

- **Music Transfer DVD has been replaced by standard Windows copy procedure**. Music files are now stored in the *Music* folder on your SD card. See page 86 of the online user guide for further Media Transfer details.
- **Map Transfer is not required**. To be informed of future map updates, please register your WorldNav 3100 at **www.TeleType.com/Register**.

POWERING YOUR GPS

When powering your device for the first time:

1. Plug the power cord into the bottom of the GPS in the hole marked DC 12V. (Do not plug cord into the Audio jack).
2. Press *Reset* button located on the back of the GPS.
3. As you drive, the battery will charge.

To conserve battery power, press and hold the Reset button located on the back until the device shuts down. To turn the device back on, simply press the Reset button once.

TeleType Co ● 20 Park Plaza ● Boston, MA 02116-4303 ● (toll free) 1-800-717-4478